



PRECEDENT CLAYS BASKET INSTALLATION INSTRUCTIONS

04-009

INCLUDED:

MADJAX CLAYS BASKET
BRACKETS
HARDWARE PACK



1
Remove bolt cover and bolts
from front struts. Retain all
factory hardware. You will
need it later.



2
Using retained factory hardware,
attach brackets to front struts.
Tighten bolts.



Attach clays basket to brackets on both sides using hardware pack.

PRECEDENT CLAYS BASKET HARDWARE PACKS

HARDWARE PACK 1

- (4) 10MM X 40MM SHOULDER HEX BOLTS
- (8) 10MM X 20MM X 2MM WASHERS
- (4) 10MM ANTI-SLIP NUTS

