



**OFF ROAD LIGHT BAR
INSTALLATION INSTRUCTIONS
MJLB8000**

**INCLUDED:
LIGHT BAR
4 PUSH PINS
WIRING HARNESS**



1

Position Light Bar on front center of vehicle canopy. Using holes on base of Light Bar as a guide, drill four 5/16" holes in canopy.



Using location of the light bar wire housing, drill a 1/2" hole in canopy. String wire loom through the hole and route down vehicle strut.

2



Attach Light Bar to vehicle canopy using Pushpins.

3

Route wire loom behind dash assembly.



4



Drill hole in dash slightly larger than switch and install switch. Route black wire to a good ground (12 volt)* and the red wire to a 12 volt * source.

IMPORTANT: Wiring to source other than 12 volts will damage light. For carts with 8 volt batteries, a 16-12V reducer is required.

5

INSTALLATION COMPLETE

VISIT WWW.MYMADJAX.COM

FOR INSTALLATION VIDEOS AND PRODUCTS